

CARRELLI TRAINAFILO/TRAINAFILI INTERMEDI PER VARIOSYNERGIC / GENERATORI DIGITALI



VR 3000



VR 3300



VR 2000



VR 143-2



VR 4000



VR 4000 Yard



VR 7000-22/11/30



VR 1500-22



VR 1500-11/12/30



VR 1530-11/12/30



VR 1530 PD



VR 1530-22

	VR 3000 VR	3300 VR	2000 VR	143-2 VR	4000 VR	4000 YARD	VR 7000 VR	7000-11 VR	7000-30 VR	1500 VR	1500-11 VR	1500-12 VR	1500-30
SISTEMA DI CONTROLLO													
Carrelli trainafilo	●	●		●									
VarioSynergic 3400	●	●		●									
VarioSynergic 4000	●	●		●									
VarioSynergic 5000	●	●											
VarioSynergic 3400-2	●	●											
VarioSynergic 4000-2	●	●											
VarioSynergic 5000-2													
TransPulsSynergic 2700 DUO					●		●						
TransSynergic 4000 / 5000 / Remote			●	●	●	●	●	●	●	●	●	●	●
TransPulsSynergic 3200 / 4000 / 5000 / Remote			●	●	●	●	●	●	●	●	●	●	●
TransPulsSynergic 7200 / 9000					● ⁽³⁾	● ⁽³⁾	● ⁽³⁾	● ⁽¹⁾	● ⁽¹⁾	● ⁽³⁾	● ⁽²⁾	● ⁽²⁾	● ⁽²⁾
Time Twin Digital							●	●	●	●	●	●	●

⁽¹⁾ 4,100,384 Necessario I-kit 2 prese 900 A!

⁽²⁾ 4,100,385 Necessario I-kit 2 prese 900 A!

⁽³⁾ Non superare 500 A al 100 %!

CARRELLI TRAINAFILO	VR 3000	VR 3300	VR 2000	VR 143-2	VR 4000	VR 4000 YARD
Velocità filo (m/min)	0 - 18	0 - 18	0,5 - 22	0,5 - 22	0,5 - 22	0,5 - 22
Filo Ø (mm)	0,8 - 1,6	0,8 - 1,6	0,8 - 1,6	0,8 - 1,6	0,8 - 1,6	0,8 - 1,6

CARRELLI TRAINAFILO	VR 7000	VR 7000-11	VR 7000-30	VR 1500	VR 1500-11	VR 1500-12	VR 1500-30
Velocità filo (m/min)	0,5 - 22	0,5 - 11	0,5 - 30	0,5 - 22	0,5 - 11	0,5 - 12	0,5 - 30
Filo Ø (mm)	0,8 - 1,6	0,8 - 3,2	0,8 - 1,6	0,8 - 1,6	0,8 - 3,2	0,8 - 3,2	0,8 - 1,6

TRAINAFILO INTERMEDIO	VR 1530-11	VR 1530-12	VR 1530-22	VR 1530-30	VR 1530-PD
TransSynergic 4000 / 5000 / Remote	●	●	●	●	●
TransPulsSynergic 3200 / 4000 / 5000 / Remote	●	●	●	●	●
TransPulsSynergic 7200 / 9000	●	●	●	●	●
Time Twin Digital	●	●	●	●	●

TRAINAFILO INTERMEDIO	VR 1530-11	VR 1530-12	VR 1530-22	VR 1530-30	VR 1530-PD
Velocità filo (m/min)	0,5 - 22	0,5 - 11	0,5 - 12	0,5 - 30	0,5 - 25
Filo Ø (mm)	0,8 - 1,6	0,8 - 3,2	0,8 - 3,2	0,8 - 1,6	1,0 - 1,6